

## Quick Installation Guide

### Hitachi Ultrastar SSD400S.B

SAS 6Gb/s Solid State Drive

Models: HUSL4040BSS600  
HUSL4020BSS600  
HUSL4010BSS600  
HUSL4040BSS601  
HUSL4020BSS601  
HUSL4010BSS601



---

## Handling precautions

---

- **CAUTION:** This drive can be damaged by ESD (Electric Static Discharge). Any damages incurred to the drive after its removal from the shipping package and the ESD protective bag are the responsibility of the user.
- Do not open the ESD bag containing the drive until you are ready to install the drive.
- Do not apply pressure on the drive during handling and installation.
- To prevent damage from impact or vibration always set the drive down gently.
- Handle the drive carefully by the edges.
- Save the packaging materials including the ESD bag in the event that the hard drive must be returned.

---

## Installing the hard drive

---

1. Record the serial number and part number of your hard drive for future reference.
  2. Turn off the computer and remove the computer system cover.
  3. Unplug the computer.
  4. Before handling the hard drive, discharge any static electricity from yourself and your clothing. With one hand touch an unpainted metal surface on the computer chassis, and then touch the ESD bag with the other hand for a minimum of two seconds.
  5. Remove the hard drive from the ESD bag.
-

## Drive Mounting

---

The drive will operate in all axes (6 directions). Performance and error rate will stay within specification limits if the drive is operated in the other orientations from which it was formatted.

The recommended mounting screw torque is 0.45 Nm (4.5 Kgf-cm). The recommended mounting screw depth is 2.5 mm maximum for bottom and 3.0 mm maximum for horizontal mounting.

Drive level vibration tests and shock tests are to be conducted with the drive mounted to a table using the bottom four screws.

---

## Turn on your computer.

---

- If the system boots, be sure the drive is recognized. If it is, turn off the computer and replace the cover. Continue to install your operating system.
- If your system does not boot up, turn off your computer and check all connections and settings. Turn on and boot the system.
- If the system fails to boot, turn off your system. Contact the Hitachi GST Support Center for assistance.

---

© 2012 Hitachi Global Storage Technologies

Produced in the United States 2/12

All rights reserved

Ultrastar is a trademark of Hitachi Global Storage Technologies. Hitachi and the Hitachi Inspire the Next logo are trademarks of Hitachi, Ltd. in the U.S., Japan and/or other countries. Other trademarks are the property of their respective company.

Hitachi Global Storage Technologies' trademarks are authorized for use in countries and jurisdictions in which Hitachi has the right to use, market and advertise the brands. Hitachi shall not be liable to third parties for unauthorized use of Hitachi trademarks.

References in this publication to Hitachi Global Storage Technologies' products, programs, or services do not imply that Hitachi intends to make these available in all countries in which it operates. Some countries have laws that may affect encryption-enabled devices. Hitachi assumes no responsibility for compliance with laws that apply to our products after they are sold or outside of our control. Accordingly, we suggest that you review all laws of the countries where you conduct business.

Product specifications provided are sample specifications and do not constitute a warranty. Information is true as of the date of publication and is subject to change. Actual specifications for unique part numbers may vary. Please visit the Support section of our website, [www.hitachigst.com/support](http://www.hitachigst.com/support), for additional information on product specifications. Photographs may show design models.

---

8 February 2012